

Zamboni Room and Snow Pit Rules

- 1.** Visitors are prohibited from entering the Zamboni operating room and the snow pit area; entry is permitted only to authorized persons and employees of the ice stadium premises.
- 2.** The Zamboni may be operated only by a trained employee of the ice stadium premises.
- 3.** A trained employee may operate the Zamboni only in accordance with the operating instructions.
- 4.** The snow pit and its technology may be operated only by a trained employee and only in accordance with the operating instructions. Service and maintenance may be performed only by a person with sufficient qualifications (see the installation, operation and maintenance manual, point 9).
- 5.** In the operating room, snow dumping after resurfacing the ice may be carried out only with one Zamboni at a time, not simultaneously with both Zambonis.
- 6.** While a Zamboni is in operation and returning from ice resurfacing to the snow pit, no other person may be present in the operating room in the direction of travel.
- 7.** A Zamboni designated for maintaining one ice surface may not drive into the hall of the second ice surface, except when one Zamboni is under repair or is undergoing inspection, control or maintenance and is parked outside the Zamboni room and snow pit operating room.
- 8.** Inspection, control and maintenance of the Zamboni may be performed only by a person authorized to do so.
- 9.** The snow pit must remain covered by the operating grate at all times, except in the case of inspection, control or maintenance of the equipment technology. In such a case, no handling of the Zamboni is permitted.
- 10.** A Zamboni may be parked in the Zamboni room and snow pit operating room only in the designated and marked place in front of the snow pit.

Operator: Pexanova s.r.o. Responsible person: Martin Holý.